

Lymphocyte Absolute CD4 Count

Order Name: **T Helper**

Test Number: 3654600

Revision Date: 05/24/2023

TEST NAME	METHODOLOGY	LOINC CODE
Lymphocyte Absolute CD4 Count	Flow cytometry	

SPECIMEN REQUIREMENTS				
Specimen	Specimen Volume (min)	Specimen Type	Specimen Container	Transport Environment
Preferred	5 mL each (3 mL each)	Whole Blood	EDTA (Lavender) and ACD Sol A/B (Yellow Top)	Room Temperature
Instructions	Collect Whole blood in Both ACD Solution A or B (Yellow Top) and EDTA (Lavender Top) . Keep whole blood, do not centrifuge or refrigerate. Deliver to the laboratory ASAP - Same Day as Collection! Collect Monday through Wednesday only. Specimens must be received at Labcorp Oklahoma Inc. by Wednesday afternoon or collect on Monday. Stability: Room Temperature: Yellow-top (ACD-A) or (ACD-B) tube: Lavender-top (EDTA) tube: 1 day			

GENERAL INFORMATION	
Testing Schedule	Testing schedule may vary.
Expected TAT	3-5 days
Clinical Use	Marker for level of immunocompetence. The T4 Lymphocytes reports out values for Lymphocyte Percent CD4 and Lymphocyte Absolute CD4
Performing Labcorp Test Code	505008
CPT Code(s)	86361
Lab Section	Reference Lab